



SWR BRIDGE - DUMMY ANT UNIT
52 OHM - 100W

ADJUST BRIDGE




SET ADS TO
MIN BEFORE APPLYING PWR

FUNCTION SWITCH




- 1-DUMMY ANTENNA
- 2-ADJ BRIDGE
- 3-READ SWR
- 4-XMIT NORMAL -
BRIDGE & DA OUT.



1-4A348-(2544) Switch Centralab 4 pole 3 sec

1- Φ -101 Ohmite Dummy Ant 52ohm 100W



- (1) 1A 295 (61M) 2 pole std plug
- (1) 1A047 (1890) Tip jack insulated Red
- (1) 1A046 (1889) Tip jack insulated Black
- (1) 38A034 (C-993) cabinet 7x10 (8 deep)
- (1) 38A014 (CB-526) chassis deck 8³/₄ x 7¹/₂
- (4) Rubber feet for cabinet screw type